



Spa Pool Start Up Kit - Chlorine

Important Tip: Always add chemicals to water, not water to chemicals

When filling, add 25ml of Crystal Water Stain & Scale Control. This will help clean the scale off the pipes.

- 1. Allow water to circulate for approximately 1 hour then add 250g of Calcium Hardener with filter running, wait for 20 minutes.
- 2. Add 250-400g of PH Buffer with filter running, wait for 20 minutes.
- 3. Test pH and adjust as necessary using either pH Increase to raise or pH Decrease to lower the level (using dessertspoon amounts).
- 4. Allow water to circulate for approximately 30 minutes. Add 50g per 1,000L CW Spa Chlor with filter running to initially oxidise the water
- 5. After 20 minutes, test the water with the AquaChek Chlorine 4:1 Test Strips to check that a 1-2 ppm Free Chlorine residual is maintained.

Daily

- Test and adjust pH accordingly 7.4-7.6 is ideal
- Test Chlorine levels. Add CW Spa Chlor always maintain a 1-2 ppm reading

Weekly

- Super chlorinate (shock dose) the pool with 50g per 1,000L Spa Chlor
- In between weekly shock dosing, add 10ml of CW Stain & Scale Control to protect your spa

If required

- Check and clean cartridge filter with CW Pool & Spa Filter Cleaner
- Use CW No Foam to control foaming
- CW Velvet Touch water enhancer giving the water a soft, velvety feel to the water.
 Clarifies and gives protection against corrosion
- CW Crystal Clear eliminates suspended dirt and organic matter that encourages bacteria and algae growth

Every 6-8 weeks

- Change the water (depending on use)
- Clean cartridge with CW Pool & Spa Filter Cleaner